



How to install Drivers


1, Extracting file from DriversInstall_3.0_10.1win10k_210k_2se10k.zip



2, First of all, right click "uninstall", select "Run as administrator"



3, Close the page



```
C:\WINDOWS\System32\cmd.exe

Total found 2 drivers need uninstall
Drivers uninstall using pnputil start


Uninstall Driver: C:\Users\Administrator\Desktop\Venturer_Bravo_S10K_Audio_Driver\drivers\Audio\isstrtc.inf

Uninstall Driver: C:\Users\Administrator\Desktop\Venturer_Bravo_S10K_Audio_Driver\drivers\Audio\rtii2sac.inf


Drivers uninstall using pnputil end

Press any key to restart device ...
```

4, Right click "install", select "Run as administrator"



5, Press "Enter" to restart



```
C:\WINDOWS\System32\cmd.exe
*****
Total found 2 drivers need install
Drivers install using infdefaultinstall start

drivers\*.fw
The system cannot find the file specified.
    0 file(s) copied.

Install Driver: C:\Users\Administrator\Desktop\Venturer_Bravo_S10K_Audio_Driver\drivers\Audio\isstrtc.inf

Install Driver: C:\Users\Administrator\Desktop\Venturer_Bravo_S10K_Audio_Driver\drivers\Audio\rtii2sac.inf

Drivers install using infdefaultinstall end
*****
Press any key to restart device ...
```

Note:

1. The files "uninstall.txt" and "install.txt" are created automatically when running
2. In terms of "Step 3", it is better to close the current page instead of restarting